

Stacking Frames

Tools Required

- Cordless Drill/Driver ■ 3/16" Allen Bit
- Rubber Mallet

Installation

Stacking Frame:

Note: Stacking capability is limited to one stacking segment.
 Not applicable to 3.5 high frame

1. Insert stacking frame base into top of frame verticals. (Figure A). Seat fully.
2. Connect stacking frame to another stacking frame using an alignment bolt or attach to a connector using a connector/end trim bolt.

Stacking on 3" extender:

1. Insert 3" extender stacker into 3" extender. Seat fully.
2. To connect the extender stacker between two stacking frames use the 5 3/4" bolts at the locations shown. (Figure A). To connect extender stacker to the end of a stacking frame use the 5" bolts at the locations shown. (Figure A).

Figure A

