

Wood or Laminate Click-Adjust Privacy Screen

Tools Required

- Cordless Drill
- #2 Philips Head Bit
- Tape Measure

Hardware Required

- #10 x 1" Phillips Panhead Screw

Installation

1. With 2 people, properly position Wood or Laminate Click-Adjust Privacy Screen onto Worksurface and fasten using #10 x 1" Phillips Panhead Screws (8 per Privacy Screen), leaving 1/8" gap between Privacy Screen and Worksurface to ensure no rubbing during adjustment of Privacy Screen. (Figure A)

Tips

1. Wood or Laminate Click-Adjust Privacy Screen can be mounted anywhere along Worksurface, but should not extend beyond edge of Worksurface after being installed. (Figure A)
2. Position of Wood or Laminate Click-Adjust Privacy Screen is held with ratcheting device, and must be raised to top of adjustment range in order to be lowered.

Figure A

