

## Receptacle

### Tools Required

- Cordless Drill/Driver
- #2 Phillips Screwdriver Bit

### Installation

1. Plug receptacle into inside of receiver block of the base wireway harness. Push in until seated and install two retaining screws. (Figure A)

### Common Configurations

#### Independent Neutral, 2 & 2 Configuration

Circuit 1	23PER110D	Circuit 3	23PER310D
Circuit 2	23PER210D	Circuit 4	23PER410D

#### Independent Neutral, 2 & 1 Configuration

Circuit 1	23PER110D	Circuit 4	23PER410D
Circuit 2	23PER210D		

#### Shared Neutral, 3 & 3 Configuration

Circuit 1	23PER110S	Circuit 4	23PER4D10S
Circuit 2	23PER210S	Circuit 5	23PER5D10S
Circuit 3	23PER310S	Circuit 6	23PER6D10S

#### Shared Neutral, 2 & 2 Configuration

Circuit 1	23PER110S	Circuit 3	23PER3D10S
Circuit 2	23PER210S	Circuit 4	23PER4D10S

#### Shared Neutral, 3 & 1 Configuration

Circuit 1	23PER110S	Circuit 3	23PER310S
Circuit 2	23PER210S	Circuit 4	23PER4D10S

Figure A

