

Transaction Counter Bracket

Tools Required

- Cordless Drill/Driver
- Tape Measure
- $\frac{3}{16}$ " Allen Bit
- #R-2 Square Screwdriver Bit
- $\frac{3}{8}$ " Drill Bit

Installation

Caution: Install two brackets for 24" to 60" counters and four brackets equally spaced for 66" to 96" counters.

1. Remove tile from one side of structure. Carefully lift up and tilt out.
Glass Tiles: Remove both sides. Carefully lift frame without glass up and tilt out. Remove anti-dislodgement wood block. Tilt frame with glass up and out.
2. Place bracket into top channel on top of frame. The frame has pre-punched holes, so no drilling is needed.
3. Position bracket over hole and insert bolt through and into receiver below, fully tighten.
4. Modify panel top cap to fit up to the transaction counter bracket and between brackets. Place top cap sections on panel.
5. Align transaction counter and attach using four #8 x .75" screws provided. (Figure A). Repeat for all brackets.
6. Reinstall tiles.

Figure A

