

Innsbruck/Osterley Park

Light Kit Installation

Tools Required

- Tape Measure
- Drill
- 2 7/8" Hole Saw

Package Contents

- Light Kit

Installation

1. Bore a 2 7/8" diameter hole in the top panel from the face side. The hole should be centered side to side and front to back in the top panel. (Figure A).
2. Install light from interior and secure in the opening with screws provided.

Figure A

