

Highback Organizer

Corner Highback Organizer

Installation

1. The highback organizer sits on top of a worksurface. It can be attached to the worksurface using the double faced tape provided.
2. Attach double faced tape to the bottom of the highback organizer end panels. Position highback unit $5/64$ " from the back and side edges of the worksurface.

Note: Double faced tape will create a strong bond. Make sure highback unit is positioned in desired location prior to final attachment. (Figure A).

Figure A

