

# Definition®

## Component Pedestal

### Tools Required

- #2 Phillips Head Bit
- Tape Measure
- Screw Gun
- Square

### Hardware Required

- #8 x 1" Panhead

### Installation

1. Typical pedestal location for desk, credenza and returns without modesty panels.  
*Note: See component return installation sheet for pedestal location of returns with modesty panels.*
2. Remove drawers from pedestals, then position pedestals upside-down on underside of worksurface.  
*Note: Make sure drawers are returned to their original location. To install, place worksurface on a clean soft surface, underside facing up.*
3. Attach pedestal to underside of top holding a margin of  $\frac{5}{64}$ " on each side and  $1\frac{1}{16}$ " from the user edge to the pedestal. Fasten pedestal metal rail and metal brackets to worksurface using #8 x 1" panhead screws. (Figure A).

Figure A

