

Footprint®

Wall Mount Spacer Strip

Tools Required

- Saw
- Black Marker

Package Contents

- Spacer Strip

Installation

1. Cut strip to cabinet width, if cabinet is less than 72" W.
2. If the strip has been cut, blacken the cut end using a black marker.
3. Remove peel strip from double stick tape. Apply strip to back of cabinet at location shown. (Figure A).

Figure A

