

Caster Protection Removal

To Remove Caster Protective Cover:

1. All Interstuhl chairs are shipped with protective caster covers. The protectors are red, blue, or yellow and are located on each side of the caster. To remove the caster protectors, simply pull the center tab and tear away from caster. Repeat this process for all five casters. (Figure A).

Figure A

