

Voice/Data and Power Modules

Tools Required

- None

Package Contents

- 1 Voice/Data Module or Power Module

Installation

1. For installation in wire manager, feed all cabling from the module through the wire management channel. Position the lower flange of the module into the rubber portion of the channel. (Figure A).

Figure A

