

Innsbruck/Osterley Park

Glass Shelf Removal and Adjustment

Tools Required

- None

Package Contents

- None

Installation

Note: Shelves are shipped uninstalled.

1. An adjustable shelf consists of a shelf and four (4) shelf support brackets. (Figure A).
2. All cabinets feature pre-bored holes 1¼" apart. Recommended spacing is #2 position, for proper ring binder clearance. (Figure B).
3. For repositioning of shelves, remove shelf and move shelf support brackets to desired hole locations. Make sure all brackets are at the same level.

Figure A




Figure B

