

# Stackable Panel Adding a Connector

## Tools Required

- Flat Blade Screwdriver
- "L" Spacers
- Socket Wrench
- Rubber Mallet
- Black Marker

## Package Contents

- Connector
- Spacer

## Installation

1. Carefully remove panel top caps by prying up one end with flat blade screwdriver or similar tool; set aside to re-use. (Figure A)
2. Remove center spring clip from any lower panel which will have a stackable panel above it. (Figure B).
3. Remove "T" connector top cap/bracket and nuts; set aside to re-use. Attach new "T" connector bracket *without* connector cap attached. (Figure C).

**Note:** Use black marker to darken frame bracket of lower panel before installing stack panel.

4. Place stackable panel **centered left to right** on top of lower panel. Place two (2) 1/4" "L" spacers on each end of panel. **(It is recommended to "bridge" the "L" Spacers between panels).** Carefully use rubber mallet to firmly seat "U" channel into spring brackets of lower panel and ensure stacker rests against spacers. Strike mallet only against studs on brackets, not fabric or wood parts of the panel. Leave spacers in place until entire section has been finished, brackets tightened and top caps replaced. Slide new connector down into position making sure "J" channels interlock. (Figure D).

Figure A




Figure B




Figure C





Figure D



Installation (continued)

5. Add additional panels as required, making sure "J" channels interlock and that the panels are *centered left to right* on top of lower panel. Position "L" spacers on each end of panel. Position "T" spacer as shown. (Figure E).  
*Note: Panels must be fully engaged in spring brackets to allow alignment and proper height of end trim and connector posts. Do not lean or load panels until all panels are secured.*
6. Join stackable panels together using top connector bracket and "T" connector bracket saved from Step 3. (Figure F).
7. Replace panel top caps saved from Step 1 by carefully tapping with a rubber mallet until fully seated and align ends with the vertical edges of the panel. (Figure G)..
8. Remove "L" spacers under panel and ACR connectors for future use. *Note: "T" and "L" spacers can be left in place under ACT and ACL connectors as blinder (optional).*

Figure E




Figure F




Figure G

