

# Definition<sup>®</sup>

## Modular End Panel

### Tools Required

- #2 Phillips Head Bit
- Tape Measure
- Screw Gun
- Square

### Hardware Required

- #8 x  $\frac{5}{8}$ " Panhead
- #10 x 1" Panhead
- #8 x 1" Flathead
- Bracket

### Installation

1. The modular end panel is used to support the end of a worksurface when a pedestal is not used. End panels are 1" less in depth than worksurfaces to accommodate a modesty panel or filler strip. (Figure A).
2. Locate the end panel  $\frac{5}{64}$ " from the front edge of the worksurface and  $\frac{5}{64}$ " from the end of the worksurface. (Figure B).
3. Secure end panel to worksurface through bracket using screws provided. (Figure C).
4. Using a framing square, make sure end panel is perpendicular to the worksurface. Attach support panel bracket to modular end panel and underside of worksurface using #10 x 1" panhead screws provided. **Note:** Locate support panel bracket in the center of the worksurface. (Figure D).

Figure A




Figure B




Figure C




Figure D

