

Definition[®]

Support Panel

Tools Required

- #2 Phillips Head Bit
- Tape Measure
- Screw Gun
- Level

Hardware Required

- #8 x 5/8" Panhead
- #8 x 5/8" Flathead
- #8 x 1" Flathead
- Bracket

Installation

1. An undersurface support panel is used to provide added support in the center of long worksurfaces where conventional support methods are not possible. These are required when kneespace area is 60" or more. (Figure A).
2. The bracket can be attached to either side of the support panel using a #8 x 5/8" panhead screw and is then attached to the underside of the worksurface using a #8 x 1" flathead screw. The bracket can be used on either side of the support panel to attach the support panel to a modesty panel. (Figure B).
3. If used with a modesty panel, the brackets are attached to the support panel with #8 x 5/8" panhead screws. The brackets are attached to the modesty panel with #8 x 5/8" flathead screws.

Figure A




Figure B

