

Xsite™ System

Worksurface Edge Support Bracket

Tools Required

- Cordless Drill/Driver
- Tape Measure
- #2 Phillips Screwdriver Bit

Installation

CAUTION: Worksurface support is required every 48". One bracket is placed at outside edges of a wrapped worksurface. One is placed at the back edge, at the corner, and every 48" for the length of the worksurface.

1. Tilt attachment plate at 45° angle and engage top edge of bracket into Xsite Traxx® at desired location. (Figure A) Lower into vertical position.
2. Determine worksurface height. Support plate will adjust in 1 1/4" increments in attachment plate for worksurface heights from 24" to 27 3/4" measured from the floor.
3. Tilt support plate at 45° angle and hook into desired slot in attachment plate. (Figure B) Lower into horizontal position.
4. Attach brackets to underside of worksurface with four #8 x 1" screws provided. (Figure C)

Figure A




Figure B





Figure C



Proper product installation, in accordance with these instructions, is the responsibility of the installing agent. If you have any questions concerning these instructions, please call Kimball Office Customer Care.

Kimball® Office