

Footprint®

Flipper Door Field Installed Lock Kit

Tools Required

- Tape Measure
- Center Punch
- $2\frac{1}{32}$ " Guide-point Wood-boring Drill Bit
- $\frac{1}{16}$ " Dia. Drill Bit
- $\frac{1}{8}$ " Dia. Drill Bit
- Electric Drill
- #2 Phillips Bit

Package Contents

- Lock Assembly
- Lock Catch "Z"
- Lock Catch "U"
- #6 x $\frac{1}{2}$ " Screws
- #8 x $\frac{5}{8}$ " Screws

Installation

Note: Field installed lock kits can be used on wood or laminate doors only.

1. Using dimensions from Figure A, mark the lock hole location with a center punch on the back of the door. Bore a $\frac{1}{8}$ " diameter pilot hole through the door. (Figure A).
2. Using the $2\frac{1}{32}$ " guide-point wood-boring drill bit, bore approximately halfway through the door. Complete boring the hole from the opposite side of the door.
3. Insert lock assembly into $2\frac{1}{32}$ " (17mm) diameter hole as shown in Figure B. Bore two pilot holes $\frac{1}{16}$ " diameter by $\frac{1}{2}$ " deep. Using the flathead screws provided, attach lock assembly to door. (Figure B).

Figure A





Figure B



Footprint

Installation (continued)

- Using dimensions shown in the chart below, mark the lock catch location with a center punch. Bore two pilot holes $\frac{1}{16}$ " diameter by $\frac{1}{2}$ " deep. (Figure C).

Nominal Cabinet Width	Dim. A	Dim. B
24"	$10\frac{9}{16}$ "	$1\frac{1}{4}$ "
30"	$13\frac{9}{16}$ "	$1\frac{1}{4}$ "
36"	$16\frac{9}{16}$ "	$1\frac{1}{4}$ "
42"	$19\frac{9}{16}$ "	$1\frac{1}{4}$ "
48"	$22\frac{9}{16}$ "	$1\frac{1}{4}$ "
60"	$13\frac{9}{16}$ "	$1\frac{1}{4}$ "
72"	$16\frac{9}{16}$ "	$1\frac{1}{4}$ "

- Using the panhead screws provided, attach the appropriate lock catch. (Figure D).

Figure C




Figure D

