

# Footprint®

## Short Storage Field Installed Lock Kit

### Tools Required

- Tape Measure
- Center Punch
- Electric Drill
- #2 Phillips Bit
- 1/16" Dia. Drill Bit
- 1/8" Dia. Drill Bit
- 2 1/32" Guide-point
- Wood-boring Drill Bit

### Package Contents

- Lock Assembly
- Lock Catch
- #6 x 1/2" Screws
- #8 x 5/8" Screws

### Installation

1. Using dimensions from Figure A, mark the lock hole location with a center punch. Bore a 1/8" diameter pilot hole through the door. (Figure A).
2. Using the 2 1/32" guide-point wood-boring drill bit, bore approximately halfway through the door. Complete boring the hole from the opposite side of the door.
3. Insert lock assembly into 2 1/32" (17mm) diameter hole as shown in Figure B. Bore two pilot holes 1/16" diameter by 1/2" deep. Using the flathead screws provided, attach lock assembly to door. (Figure B).
4. Using dimensions from Figure C, mark the lock catch location on side panel with a center punch. Bore two pilot holes 1/16" diameter by 1/2" deep. (Figure C).
5. Using the panhead screws provided, attach the lock catch to the side panel. (Figure D).

Figure A




Figure B




Figure C




Figure D

