

Xsite®

Vertical Cable Manager

Tools Required

- None

Package Contents

- Vertical Cable Manager

Installation

1. The vertical cable manager attaches to Xsite between a worksurface and an overhead. (Figure A). Worksurface must have a wire manager to allow the cable manager to engage in the Traxx®.
2. Position the top tab on the cable manager between the overhead and the tile. If the cable manager is installed under a radius or square profile overhead, the cable manager may be installed at any point along the unit. (Figure B). If the cable manager is installed under a Lunar or Bevel profile overhead, the cable manager can only be installed at either end of the unit with the long tab behind the overhead mounting brackets. (Figure C).
3. Once the cable manager is in the desired location with the top tab positioned, insert the clip on the bottom of the cable manager into the Traxx channel behind the worksurface. To engage the clip, push at the bottom of the cable manager until a “click” is heard. To remove clip, lift up on the small tab at the bottom. (Figure D). Be careful not to pull or twist the cable manager once the Traxx clip engages.

Figure A




Figure B




Figure C





Figure D



Proper product installation, in accordance with these instructions, is the responsibility of the installing agent. If you have any questions concerning these instructions, please call Kimball Office Customer Service.

Kimball®Office